



Application Instructions For Gloss SX

Step One: Mix Part A and Part B together at a 5:1 Ratio

For Example: 50ml of A : 10 ml of B

Step Two: Mix together thoroughly

Application: you can put the material directly on the surface and roll in out normally at 2 mills. After it's rolled out, you may want to lightly back roll the surface to get rid of any roller lines. A 3/8 in nap roller works best. Foam roller will also work.

NOTE: If you are mixing a full kit you don't need to measure anything out you just need to put the 2 components together and mix thoroughly.