



ELASTOCRETE

LIMITLESS CONCRETE

## Application Instructions For Super Prime 4.0

Use a harmful vapor filter mask when working with material.

**Step One:** Mix Part A and Part B Together at a 30:1 Ratio.

**Step Two:** Apply the primer with a 3/8" non-shedding nap roller. Do not pour the primer directly on the concrete (this may cause discolorations). Place the material in a roller pan, saturate the roller, making sure to not oversaturate. Oversaturation will leave drips on application surface that are unwanted.

**Step Three:** Apply the primer on the concrete with one thin coat. Use firm pressure when rolling out the material. Work the material into the surface. Apply thin 1-1.5 mil thickness. Make sure you get the whole surface covered evenly.

**NOTE:** Apply your topcoat when the primer is dry to the touch. The primer should dry in about 2-3 hours. (If you apply primer on top of grout that is not fully cured, it could take up to 24 hours for the primer to dry). We recommend waiting 24 hours to seal the concrete after grouting.

**NOTE:** In a sealed container, material should have a 2-week shelf life after mixing.

**NOTE:** One-gallon kit will cover roughly 400-600 Sq. Ft.