



Application Instructions For Matt SX

Ratio: 6 parts A: 1 part B (by volume) Total volume in ML X 13% = part c in grams

Step one: Mix Part A and Part C (Matting Additive) together. Make sure to mix thoroughly and mechanically with a plastic mixing paddle on a power drill. The powder must be sheared into the part A until there are no powder micro pockets left. This usually requires shearing for 2 minutes. Swishing the mixing container around to let the sheared material run up the sides and looking for white dots is a good way to tell if the material is sheared enough.

Step two: Add part B. Mechanically mix for 2 minutes.

Ratio to get part C: (A (in ml) + B (in ml)) X .13 = C in Grams

EXAMPLE: 60 ml of A + 10 ml of B = 70 ml Total

$70 \times .13 = 9$ Grams of Part C

End Ratio:

Part A 60 ml
Part B 10 ml
Part C 9 Grams

Application: Use a 3/8 in non-shedding nap roller to apply the sealer. You can put the material directly on the surface and roll in out normally at 2 mills. After it's rolled out, lightly back roll the surface to get rid of any roller lines.

NOTE: If you are mixing a full kit you don't need to measure anything out you just need to put the 3 components together and mix. Mixing A and c together first then add part B last

NOTE: Coverage will be approximately 600-800 Sq. Ft. per gallon and approximately 200 per quart.