



## Application Instructions For Satin SX

**Ratio:** 6 parts A: 1 part B (by volume) Total volume in ML X 10% = part c in grams

**Step one:** Mix Part A and Part C (Matting Additive) together. Make sure to mix thoroughly and mechanically with a plastic mixing paddle on a power drill. The powder must be sheared into the part A until there are no powder micro pockets left. This usually requires shearing for 2 minutes. Swishing the mixing container around to let the sheared material run up the sides and looking for white dots is a good way to tell if the material is sheared enough.

**Step two:** Add part B. Mechanically mix for 2 minutes.

**Ratio to get part C:** (A (in ml) + B (in ml)) X .1 = C in Grams

**EXAMPLE:** 60 ml of A + 10 ml of B = 70 ml Total

$70 \times .10 = 7$  Grams of Part C

**End Ratio:**

Part A 60 ml

Part B 10 ml

Part C 7 Grams

**Application:** Use a 3/8 in non-shedding nap roller to apply the sealer. You can put the material directly on the surface and roll in out normally at 2 mills. After it's rolled out, lightly back roll the surface to get rid of any roller lines.

**NOTE:** If you are mixing a full kit you don't need to measure anything out you just need to put the 3 components together and mix. Mixing A and c together first then add part B last

**NOTE:** Coverage will be approximately 600-800 Sq. Ft. per gallon and approximately 200 per quart.